



## **HD EXPLORA AND 4U DECODER SETTINGS ON A ONE CABLE SYSTEM**

(Please note that the switch MUST NOT be installed when connecting an Explora decoder to a one cable system.)

Press [BLUE BUTTON] followed by [>] to find SETTINGS then use [V] to select SATELLITE SETTINGS.

Press [>] to select Home Network and press [OK ]

Press [>] to change Unicable™/SatCR to SMATV

Press [V] to select the horizontal frequencies and match up the input to the output frequencies as follows:

In most case OUTPUT NEW will be the one that binds, if not try OUTPUT OLD2 followed by OUTPUT OLD1

<b>INPUT</b>	<b>OUTPUT (OLD1)</b>	<b>OUTPUT (OLD2)</b>	<b>OUTPUT (NEW)</b>
10970 H (1220)	11210 (1460)	11210 (1460)	11210 (1460)
11010 H (1260)	11250 (1500)	11290 (1540)	11250 (1500)
11050 H (1300)	11370 (1620)	11370 (1620)	11290 (1540)
11090 H (1340)	11410 (1660)	11410 (1660)	11330 (1580)
11130 H (1380)	11330 (1580)	11330 (1580)	11370 (1620)
11170 H (1420)	11290 (1540)	11250 (1500)	11410 (1660)
11474 H (1724)	10930 (1180)	10930 (1180)	10930 (1180)
11514 H (1764)	10890 (1140)	10890 (1140)	10890 (1140)
11554 H (1804)	10850 (1100)	10850 (1100)	10850 (1100)
11594 H (1844)	10810 (1060)	10810 (1060)	10810 (1060)
11634 H (1884)	10770 (1020)	10770 (1020)	10770 (1020)
11674 H (1924)	10730 (980)	10730 (980)	10730 (980)

All vertical frequencies can stay on default 0